

tailed information on blast status, location etc. Radio users can still talk normally on their designated user group, however they will hear the blast alarm intermittently in the background.

- Continuous Blast Alarm across the network.
- Simple one button press activation.
- Talkgroup selection
- Wave file selection (4 to choose from Wave 0 4)
- O Number of repeat cycles to play-out wave file





